



Never float a butt joint again!

EZ-Taper™ allows butt edge tapers to be made on site, as needed, with standard tools and materials. Saves time and results in flatter walls.

All drywall has factory tapers on the long edges but standard thickness ends. Whenever a layout requires a joint between butt edges, considerable effort is required to feather the bulge created by the tape. Even then the bulge is still present, just spread over a wider area.

- Quicker than floating butts
- Eliminates butt bulges
- No special tools
- No special materials
- Allows joints directly to existing studs



EZ-Taper is available in 48" and 54" lengths. They come in packs of 10 or boxes of 100 pieces.

*Fulcrum Composites, Inc.
1407 E. Grove St.
Midland, MI 48640*

*Ph: 989-636-1025
Fax: 989-837-1566*
www.fulcrumcomposites.com/curve.html
info@fulcrumcomposites.com

EZ-Taper



Clamp fence onto standard cut-off saw 1/16" from 0.1" (not 0.080") blade. Set blade depth to 1 5/8".



Run a knife down the taper to squeeze out excess mud.



Run saw along butt edge face side.



Screw board in place while mud is still wet. If edges pop up between screws staple like vinyl corners.



Butter EZ Taper wedge with mud and insert into slot, thick edge first



Tape, mud & finish as normal – for a perfectly flat joint without the hassle of feathering out the butt.

Fulcrum Composites, Inc.
1407 E. Grove St.
Midland, MI 48640

Ph: 989-636-1025
Fax: 989-837-1566
www.fulcrumcomposites.com/curve.html
info@fulcrumcomposites.com